

Maintenance Schedule

Performing regular maintenance according to the factory-recommended Maintenance Schedule is the best way to keep your Honda running in optimal condition.

Each vehicle has its own maintenance needs, so Honda develops specific maintenance schedules based on model equipment, such as transmission choice or the addition of a towing package.

The Maintenance Schedule calculates service needs based on your car's mileage. It checks engine-operating conditions and helps coordinate oil service dates and other maintenance check-ups. Prevent problems before they occur.

In order to view the maintenance schedule for a specific vehicle, please sign in — to view a saved vehicle — or choose a model.

[Normal](#)

Severe

7,500 mi/12,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

7,500 mi/12,000 km/1 yr

6 Speed Manual - Recommended service:

- Replace engine oil

15,000 mi/24,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

15,000 mi/24,000 km/1 yr

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- #: See information on maintenance and emissions warranty, middle column, page 122 of your [owner's manual](#)).

15,000 mi/24,000 km/2 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

22,500 mi/36,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

22,500 mi/36,000 km/3 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

Every 3 years (independent of mileage)

6 Speed Manual - Recommended service:

- Replace brake fluid

30,000 mi/48,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition
- Replace air cleaner element

30,000 mi/48,000 km/2 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- [#]: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual).
- Inspect drive belts
- Replace dust and pollen filter

- Replace rear differential fluid

30,000 mi/48,000 km/4 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

37,500 mi/60,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

37,500 mi/60,000 km/5 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

45,000 mi/72,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

45,000 mi/72,000 km/3 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- [#]: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual.

45,000 mi/72,000 km/6 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

52,500 mi/84,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

52,500 mi/84,000 km/7 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

60,000 mi/96,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition
- Replace air cleaner element

60,000 mi/96,000 km/4 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- #: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual.
- Inspect drive belts
- Replace dust and pollen filter
- Replace rear differential fluid

60,000 mi/96,000 km/8 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

67,500 mi/108,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

67,500 mi/108,000 km/9 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

75,000 mi/120,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

75,000 mi/120,000 km/5 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- [#]: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual).

75,000 mi/120,000 km/10 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

82,500 mi/132,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

82,500 mi/132,000 km/11 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

90,000 mi/144,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition
- Replace air cleaner element

90,000 mi/144,000 km/6 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- #: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual.
- Inspect drive belts
- Replace dust and pollen filter
- Replace rear differential fluid

90,000 mi/144,000 km/12 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

97,500 mi/156,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

97,500 mi/156,000 km/13 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

105,000 mi/168,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition
- Replace spark plugs

- Inspect valve clearance, otherwise adjust only if noisy
- Inspect idle speed

105,000 mi/168,000 km/7 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- #: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual).

105,000 mi/168,000 km/14 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

112,500 mi/180,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

112,500 mi/180,000 km/15 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

120,000 mi/192,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition
- Replace air cleaner element

120,000 mi/192,000 km/8 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- #: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual).
- Inspect drive belts
- Replace dust and pollen filter
- Replace manual transmission fluid
- Replace rear differential fluid

120,000 mi/192,000 km/10 yrs

6 Speed Manual - Recommended service:

- Replace engine coolant, then every 60,000 miles (96,000 km) or 5 years.

120,000 mi/192,000 km/16 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

127,500 mi/204,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

127,500 mi/204,000 km/17 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

135,000 mi/216,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

135,000 mi/216,000 km/9 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots
- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- #: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual).

135,000 mi/216,000 km/18 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

142,500 mi/228,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition

142,500 mi/228,000 km/19 yrs

6 Speed Manual - Recommended service:

- Replace engine oil

150,000 mi/240,000 km

6 Speed Manual - Recommended service:

- Check tires inflation and condition
- Replace air cleaner element

150,000 mi/240,000 km/10 yrs

6 Speed Manual - Recommended service:

- Replace engine oil filter
- Check front and rear brakes
- Check parking brake adjustment
- Inspect tie-rod ends, steering gearbox, and boots
- Inspect suspension components
- Inspect driveshaft boots

- Inspect brake hoses and lines (including ABS)
- Inspect all fluid levels and condition of fluids
- Inspect exhaust system[#]
- Inspect fuel lines and connections[#]
- #: See information on maintenance and emissions warranty, middle column, page 122 of your owner's manual).
- Inspect drive belts
- Replace dust and pollen filter
- Replace rear differential fluid

150,000 mi/240,000 km/20 yrs

6 Speed Manual - Recommended service:

- Replace engine oil